



- GENERAL NOTES
- 1- USE A MINIMUM OF 1.44+/- SQ. INCH AREA FOR EACH REFLECTIVE LENS.

2- SAWCUT GROOVES TO DIMENSIONS PROVIDED BY THE MANUFACTURER.

3- CONTACT ALL LEVELING LUGS TO THE PAVEMENT SURFACE.

4- REFLECTOR DIMENSIONS CAN VARY, BUT DESIGNED TO FIT IN THE CASTING AND PROVIDE THE REQUIRED REFLECTIVITY.

